











Volkswagen	Passat	2006	2013											
Volkswagen	Polo I & II	1982	1993											
Volkswagen	Polo III & IV & V	1994	2013	5.81250K(bolts)	-1.75 degree to +1.75 degree									
Volkswagen	Scirocco	1974	1992											
Volkswagen	Scirocco	2009	2013						5.75200K(ahim)	-1.5 degrees to +1.5 degrees			5.75200K(ahim)	-1.5 degrees to +1.5 degrees
Volkswagen	Sharan	1995	2011						5.75200K(ahim)	-1.5 degrees to +1.5 degrees			5.75200K(ahim)	-1.5 degrees to +1.5 degrees
Volkswagen	Tiguan	2009	2013											
Volkswagen	Touran	2003	2011											
Volkswagen	Touareg	2003	2011											
Volkswagen	Vento	1991	1998	5.81250K(bolts)	-1.75 degree to +1.75 degree				5.75200K(ahim)	-1.5 degrees to +1.5 degrees			5.75200K(ahim)	-1.5 degrees to +1.5 degrees
Volvo	240	1980	1991											
Volvo	400 Series	1988	1997	5.81250K(bolts)	-1.75 degree to +1.75 degree									
Volvo	650 GLE	1993	1997	5.81250K(bolts)	-1.75 degree to +1.75 degree				5.75800K(ahim)	-1.5 degrees to +1.5 degrees			5.75800K(ahim)	-1.5 degrees to +1.5 degrees
Volvo	950	1995	1997	5.81250K(bolts)	-1.75 degree to +1.75 degree									
Volvo	C 30	2008	2013											
Volvo	S40/V40	1998	2004	5.81250K(bolts)	-1.75 degree to +1.75 degree				5.81310K(bolts) OR 5.87420K(arms)	5.81310K -1.0 to +1.0; 5.87420K -1.5 to +5.0				
Volvo	S40/V40/V90	2005	2013						5.81310K(bolts) OR 5.87420K(arms)	5.81310K -1.0 to +1.0; 5.87420K -1.5 to +5.0				
Volvo	S60	2000	2011	5.81260K(bolts)	-1.75 degree to +1.75 degree									
Volvo	S70/V70	1998	2009	5.81250K(bolts)	-1.75 degree to +1.75 degree									
Volvo	S70/V70	2007	2013											
Volvo	S 80	2007	2013											
Volvo	S 80	1999	2008	5.81260K(bolts)	-1.75 degree to +1.75 degree									
Volvo	S/V 90	1996	1998	5.81250K(bolts)	-1.75 degree to +1.75 degree									
Volvo	XC90	2000	2013											
Volvo	XC70	2001	2007	5.81260K(bolts)	-1.75 degree to +1.75 degree									
Volvo	XC90	2002	2013	5.81260K(bolts)	-1.75 degree to +1.75 degree									

**Shim set includes**

Toe Shims (x2 of each)  
 5.71520 (+/- 0.13 degree)  
 5.71521 (+/- 0.25 degree)  
 5.71522 (+/- 0.38 degree)  
 5.71523 (+/- 0.50 degree)

**Camber**

5.71530 (+0.50 degree)  
 5.71531 (+1.00 degree)  
 5.71532 (-0.50 degree)  
 5.71533 (-1.00 degree)

**Tool**

5.87530 - VW Shim Wrench

These can all be purchased individually

**\*\* Honda Shims**

Toe  
 5.71641 (+0.13 degree)  
 5.71642 (+0.25 degree)  
 5.71643 (+0.38 degree)  
 5.71644 (+0.50 degree)  
 5.71645 (-0.13 degree)  
 5.71646 (-0.25 degree)  
 5.71647 (-0.38 degree)  
 5.71648 (-0.50 degree)

**Camber**

5.71651 (+ 0.50 degree)  
 5.71652 (+ 1.00 degree)

**\*\*\* Peugeot Shims**

Toe and Camber  
 5.71851 (+ 0.06 degree)  
 5.71852 (+ 0.13 degree)  
 5.71853 (+ 0.25 degree)  
 5.71854 (+ 0.50 degree)  
 5.71855 (+ 0.75 degree)  
 5.71856 (+ 1.00 degree)

**\*\*\*\* Renault Shims**

Toe and Camber  
 5.71861 (+ 0.50 degree)  
 5.71862 (+1.00 degree)